




DOMESTIC WATER HEAT PUMP **User and Installation Manual**



FLEXUS

FX-080VP XA

FX-120VP XA

Thank you for choosing our product. For proper operation, please read this manual carefully and keep it safe. If you lose this manual, please contact your installer or visit www.nipon-coolair.com, or email geral@nipon-coolair.com to obtain a digital version.



Content




Explanation of the symbols presented in the unit.....	5
Safety Instructions	5
INTRODUCTION	11
This manual.....	11
SAFETY INSTRUCTUINS	12
ITEMS INSIDE PRODUCT BOX.....	15
OVERVIEW OF THE UNIT.....	16
Parts and description.....	16
Dimensions	17
How to replace the magnesium stick	18
Schematic overview of the water and refrigeration circuit.....	18
INSTALLATION.....	19
WARNING.....	19
Required service space	20
Intallation overview	21
Installation Positions.....	22
Water loop connection.....	23
Water filling and water emptying.....	23
Wire connection	24
Trial runnig.....	24
OPERATION THE UNIT.....	25
User interface and operation.....	25
.....	25
LED icons.....	27
WIFI.....	29
PARAMETER CHECKING AND ADJUSTMENT.....	37
Parameter list.....	37
Malfunctioning of the unit and error codes	38
MAINTENANCE	40
TROUBLESHOTING	41
No image on the controller (blank display). Check if the main power is still connected.	41

One of the error codes appears, consult your local dealer.....	41
The scheduled timer does work but the programmed actions are executed at the wrong time (e.g. 1 hour too late or too early). Check if the clock and the day of the week are set correctly, adjust it if necessary.....	41
ENVIRONMENTAL INFORMATION.....	41
This equipment contains R290 refrigerant in the amount as stated in the specification. Do not vent R290 into the atmosphere: R290 is with a Global Warming Potential (GWP) = 3°	41
DISPOSAL REQUIRIMENTS	41
WIRING DIAGRAM	42
TECHNICAL SPECIFICATION.....	43
TECHNICAL DATA.....	43
TEMPERATURE SENSOR R-T CONVERSION TABLE.....	45

Note:

-  READ THIS MANUAL CAREFULLY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY. Keep it in your files for future reference.
-  BEFORE OPERATING THE UNIT, MAKE SURE THE INSTALLATION HAS BEEN CARRIED OUT CORRECTLY BY A PROFESSIONAL DEALER. IF YOU FEEL UNSURE ABOUT OPERATION, CONTACT YOUR DEALER FOR ADVICE AND INFORMATION.

Explanation of the symbols presented in the unit

	WARNING	This symbol shows that this appliance used a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.
	CAUTION	This symbol shows that the operation manual should be read carefully.
	CAUTION	This symbol shows that information is available such as the operating manual or installation manual.
	CAUTION	This symbol shows that a service personnel should be handling this equipment with reference to the installation manual.

Safety Instructions

In order to prevent personal injury or property damage to users and others, please be sure to follow the following instructions. If ignoring the prompt or wrong operation may cause injury or damage. The unit shall be installed in compliance with local laws, regulations and standards. Check the voltage and frequency. This machine is only used for grounding socket., must be reliably connected to the ground.

The following security precautions need to be taken into account :

- Please read the following warnings before installing.
- Please be sure to check the details that need attention, which includes many contents related to security issues.
- After reading the installation instructions, be sure to keep them for future reference.

Warning

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face danger of death by suffocation.

Safely dispose of packing materials such as nails and other metal or wood parts that could cause injuries.

Ensure that the installation of Indoor and outdoor unit is safe and reliable.

If the machine is not installed firmly or not properly, it will cause damage. The minimum support weight required for installation is 20g/mm², and full consideration should be given to strong winds, hurricanes or earthquakes. When installing the machine in a closed area or limited

space, please consider the size and ventilation of the room to prevent suffocation due to refrigerant leakage.

- That the appliance shall be disconnected from its power source during service and when replacing parts and, if that the removal of the plug is foreseen, it shall be clearly indicated that the removal of the plug has to be such that an operator can check from any of the points to which he has access that the plug remains removed.
- If this is not possible, due to the construction of the appliance or its installation, a disconnection with a locking system in the isolated position shall be provided.
- Improper installation of equipment or accessories may result in electric shock, shortcircuit, leakage, fire or other damage to the equipment. Be sure to only use accessories made by the supplier, which are specifically designed for the equipment and make sure to get installation done by a professional.



Caution: Risk of fire flammable materials

- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
 - All the activities described in this manual must be carried out by a licensed technician. Be sure to wear adequate personal protection equipment such as gloves and safety glasses while installing the unit or carrying out maintenance activities.
 - The appliance shall be installed in accordance with national wiring regulations.
 - Use a specific wire and fix it on the terminal block (so that the connection can avoid the pressure of the wire from being applied to the component).
 - Incorrect wiring can cause fire.
 - Make certain that all electrical work is carried out by qualified personnel according to the local laws and regulations and this manual. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or fire.
 - Be sure to install a ground fault circuit interrupter according to local laws and regulations. Failure to install a ground fault circuit interrupter may cause electric shocks and fire.
 - During installation or repair of the unit, please do not unplug or plug in the power supply, and do not leave the unit unattended.(It may cause fire or electric shock)
 - Do not touch or operate the unit when your hands are wet.(It may cause fire or electric shock)
- Before touching electric terminal parts, turn off power switch.

- When service panels are removed, live parts can be easily touched by accident.
- Do not touch water pipes during and immediately after operation as the pipes may be hot and could burn your hands. To avoid injury, give the piping time to return to normal temperature or be sure to wear protective gloves.
- Before touching electrical parts, turn off all applicable power to the unit
- After completing the installation work, check to make sure that there is no refrigerant leakage.
- Never directly touch any leaking refrigerant and the refrigerant pipes. It could cause severe frostbite. During and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor and other refrigerant cycle parts. Burns or frostbite are possible if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear protective gloves.

Do not touch the internal parts (pump, backup heater, etc.) during and immediately after operation

- **Touching the internal parts can cause burns. To avoid injury, give the internal parts time to return to normal temperature or, if you must touch them, be sure to wear protective gloves.**
- **Do not place heaters or other electrical appliances near the power cord** (It may cause fire or electric shock)
- **Please note that water cannot be poured directly from the unit. Do not let water enter electrical components.** (It may cause fire or electric shock)



If the unit is not used for a long time, it is recommended not to turn off the power supply. If the power is turned off, the protection devices of some products (such as water pump anti lock and anti freezing device) will not be available.



Cautions


- **Please carry out drainage system and the pipeline work according to the instructions.**

If the drainage system or pipeline is defective, water leakage may occur, and it should be dealt with immediately to avoid getting other household products wet and damaged.

- **Install the power wire at least 3 feet (1 meter) away from televisions or radios to prevent interference or noise. (Depending on the radio waves, a distance of 3 feet (1 meter) may not be sufficient to eliminate the noise.)**
- **Please do not clean the unit when the power is on. When cleaning the unit, please turn off the power after shutting down. Otherwise, you may be injured by a highspeed fan or electric shock.**
- **Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.**
- **Do not wash the unit. This may cause electric shocks or fire.**

- **Do not install the unit in the following places:**

- Where there is mist of mineral oil, oil spray or vapors. Plastic parts may deteriorate, and cause them to come loose or water to leak.
- Where corrosive gases (such as sulfurous acid gas) are produced. Where corrosion of copper pipes or soldered parts may cause refrigerant to leak.
- Where there is machinery which emits electromagnetic waves. Electromagnetic waves can disturb the control system and cause equipment malfunction.
- Where flammable gases may leak, where carbon fiber or ignitable dust is suspended in the air or where volatile flammables such as paint thinner or gasoline are handled. These types of gases might cause a fire.
- Where the air contains high levels of salt such as near the ocean.
- Where voltage fluctuates a lot, such as in factories.
- Where voltage fluctuates a lot, such as in factories.
- Where acidic or alkaline vapors are present.



- This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

- **DISPOSAL: Do not dispose this product as unsorted municipal waste**

Collection of such waste separately for special treatment is necessary. Do not dispose of electrical appliances as municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substance can leak into the groundwater and get into the food chain, damaging your health and well-being.

- **Confirm the safety of the installation area (walls, floors, etc.) without hidden dangers such as water, electricity, and gas before wiring/pipes.**
Before installation , check whether the user's power supply meets the electrical installation requirements of unit (including reliable grounding , leakage , and wire diameter electrical load, etc.). If the electrical installation requirements of the product are not met, the installation of the product is prohibited until the product is rectified.
- **Product installation should be fixed firmly, Take reinforcement measures, when necessary.**
- **When the unit has problems or peculiar smell, please do not continue to operate the unit.**

Turn off the power immediately and stop the machine. Otherwise, electric shock or fire may be caused.

- **Please be careful when the product is not packaged or installed.**

Harp edges can cut people. Take special care of the edges and fins of the heat exchanger.

- **After installation or maintenance, please check whether the refrigerant or refrigerant will leak.**

If the refrigerant is insufficient, the unit will not work normally.

- **The installation of external and internal machines must be flat and firm.**

Avoid vibration and water leakage.

- **Do not put your fingers into the fan and evaporator.**
High speed fans can cause serious injury.
- **In order to avoid the danger of inadvertently resetting the thermal breaker, the 5 equipment cannot use external switching devices, such as timers, or be connected to a circuit that is often open or closed.**
- **This device is not designed for people with weak physical or mental behavior ability (including children), as well as people who have no use experience and do not understand the heating system. Unless it is used under the safety guidance and supervision of the person in charge, or has received training on the use of this equipment. Children should use the equipment under the supervision of adults to ensure their safe use of the equipment.**
- **If the power cord is damaged, it must be replaced by the manufacturer or its service agent or the same professional person to avoid danger. The cut-off device shall be incorporated into the fixed wiring, and the contact spacing gap of each effective conductor shall be at least 3mm.**



Special requirements for R290

- **Do NOT have refrigerant leakage and open flame.**
- **Be aware that the R290 refrigerant does NOT contain an odour.**
- **The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example: open flames, an operating gas appliance) and the room size corresponds to the room area as specified for operation.**
- **Joints made in installation between parts of refrigerant system shall be accessible for maintenance purposes.**
- **Make sure installation, servicing, maintenance and repair comply with instructions and with applicable legislation (for example national gas regulation) and are executed only by authorized persons.**
- **Pipework should be protected from physical damage.**



About hydrocarbon refrigerant

- - This air to water heat pump unit contains hydrocarbon refrigerant. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself. Compliance with national gas regulations shall be observed.
- Installation, service, maintenance and repair of this unit must be performed by a certified technician.
- Product installation and recycling must be performed by a certified technician.

- If the system has a leak-detection system installed, it must be checked for leaks at least every 12 months. When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended.

INTRODUCTION

This manual

This manual includes the necessary information about the unit. Please read this manual carefully before you use and maintain the unit.

The heat pump unit

The hot water heat pump is one of the most economical systems to heat the water for family domestic use. Using free renewable energy from the air, the heat pump unit is highly efficient with low running costs. Its efficiency can be up to 3 ~ 5 times more than conventional gas boilers or electrical heaters.

Waste Heat recovery

Units can be installed near the kitchen, in the boiler-room or the garage, basically in every room which has a large number of waste-heat so that the unit has the higher energy efficiency even with very low outside temperatures during the winter.

Hot water and dehumidifier

Units can be placed in the laundry room or clothing room. When it produces hot water it lowers the temperature and dehumidifies the room as well. The advantages can be experienced particularly in the humid season.

Storage room cooling

Units can be placed in the storage room as the low temperature keeps the food fresh.

Hot water and fresh air ventilation

Units can be placed in the garage, gym, basement etc. When it produces hot water, it cools the room and supplies fresh air.

Compatible with different energy sources

Units can be compatible with solar panels, external heat pumps, boilers or other different energy sources.

Ecological and Economical Heating

Units are the most efficient and economical alternative to both fossil fuel boilers and heating systems. By making use of the renewable heating source in the air, it consumes much less energy.

Compact design

Units are especially designed for offering sanitary hot water for family use. Its extremely compact structure and elegant design are suitable for indoor installation.

Multiple Functions

The special design of the air inlet and outlet makes the unit suitable for various ways of connections. With different ways of installation, the unit can work as just a heat pump but also as a fresh air blower, a dehumidifier, or an energy recovery device.

Other features

Stainless steel tank and a magnesium stick assure the durability of components and the tank.

High-efficient R290 specialized compressor.

Electrical element is available in the unit as a back-up, assuring constant hot water even in extreme cold winters.

SAFETY INSTRUCTUINS

To prevent injury to the user, other people, or property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage..

Install the unit only when it complies with local regulations, by-laws and standards. Check the main voltage and frequency. This unit is only suitable for earthed sockets, connection voltage 220 – 240 V ~ / 50Hz.

The following safety precautions should always be taken into account:

- Be sure to read the following WARNING before installing the unit.
- Be sure to observe the cautions specified here as they include important items related to safety.
- After reading these instructions, be sure to keep it in a handy place for future reference.



Warning

Do not install the unit yourself.

Incorrect installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or a specialized installer.

Install the unit securely in place.

When insufficiently installed, the unit could fall causing injury. The bearing surface should be flat to bear the weight of the unit and suitable for installing the unit without increasing noise or vibration. When installing the unit in a small room, please take measures (like sufficient ventilation) to prevent the asphyxia caused by the leakage of refrigerant.

Use the specified electrical wires and attach the wires firmly to the terminal board (connection in such a way that the stress of the wires is not applied to the sections).

Incorrect connection and fixing could cause a fire.

Be sure to use the provided or specified parts for the installation work.

The use of defective parts could cause an injury due to possible fire, electric shocks, the unit falling etc.

Perform the installation securely and please refer to the installation instructions.

Incorrect installation could cause an injury due to possible fire, electric shocks, the unit falling, leakage of water etc.

Perform electrical work according to the installation manual and be sure to use a dedicated section, fused with 16A.

If the capacity of the power circuit is insufficient or there is an incomplete electrical circuit, it could result in a fire or an electric shock.

The unit must always have an earthed connection.

If the power supply is not earthed, you may not connect the unit.

Never use an extension cable to connect the unit to the electric power supply.

If there is no suitable, earthed wall socket available, have one installed by a recognized electrician.

Do not move/repair the unit yourself.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or similarly qualified person in order to avoid a hazard. Improper movement or repair on the unit could lead to water leakage, electrical shock, injury or fire.

The unit is no intended for use by children.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Do not tear the labels on the unit.

The labels are for the purpose of warning or reminding, keeping them to ensure your safe operations.

 Caution

Do not install the unit in a place where there is a chance of flammable gas leaks.

If there is a gas leak and gas accumulates in the area surrounding the unit, it could cause an explosion.

Perform the drainage/piping work according to the installation instruction.

If there is a defect in the drainage/piping work, water could leak from the unit and household goods could get wet and be damaged.

Do not clean the unit when the power is 'ON'.

Always shut 'OFF' the power when cleaning or servicing the unit. If not, it could cause an injury due to the high speed running fan or an electrical shock.




Do not continue to run the unit when there is something wrong or there is strange smell. The power supply needs to be shut 'OFF' to stop the unit, otherwise this may cause an electrical shock or fire.

Do not put your fingers or others into the fan, or evaporator.

The inside parts of the heat pump may run at high speed or high temperature, they could cause serious injury. Do not remove the grills on the fan outlet and top cover. The hot water needs to be mixed with cold water for terminal usage, too hot water (over 50°C) in the heating unit may cause injury.


ITEMS INSIDE PRODUCT BOX

Before starting the installation, please make sure that all parts are found inside the box.


The drive box		
Item	Image	quantity
Domestic hot water heat pump		1
Operation and Installation Manual		1
Fixing bracket		2
Screws		4
Screws with metal bushings		4

OVERVIEW OF THE UNIT

Parts and description



Dimensions




	80L	120L
A	100	100
B	100	100
C	100	100
D	625	876
E	Φ 160	Φ 160
F	20	20
G	Φ 516	Φ 516
H	230	230
I	1070	1317
J	640	890
K	116	116
L	484	540
M	225	225
N	270	270
O	45°	45°

Remark:

1) The Magnesium stick is an anti-corrosion element. It is assembled in the water tank to avoid the corrosion around the inside tank and to protect the tank, and other components. It can help to extend the life-span of the tank. **Check the magnesium stick every half year and change it if it has been use out!**

**How to replace the magnesium stick**

- Turn the power of the unit 'OFF' and pull out the plug.
- Drain all the water out of the tank.
- Remove the old magnesium stick from the tank.
- Replace the new magnesium stick.
- Recharge the water.

Schematic overview of the water and refrigeration circuit**Reference for selecting the appropriate unit**

Consult the table below to choose the appropriate unit for each situation

Number of users	Tank capacity
1~2 people	80L~100L
2~3 people	120L

Note: The table is for reference only.

INSTALLATION



WARNING

- ❑ Asked your supplier to install the unit. Incomplete installation performed by yourself may result in a water leakage, electric shock, or fire.
- ❑ Indoor installation is highly recommended. It is not allow to install the unit at outdoor or rain achieving place.
- ❑ The installation place without direct sunlight and other heat supplies is recommended. If no way to avoid these, please install a covering.
- ❑ The unit must be securely fixed to avoid noise and shaking.
- ❑ Make sure that there's no obstacle around the unit.

Transportation


As a rule, the unit is to be stored and/or transported in its shipping container in upright position and without water charge. For a transport over short distance (provided that it is done with care), an inclination angle up to 30 degrees is permitted, both during transport and storage. Ambient temperatures of -20 to $+70$ degrees Celsius are permitted..

- Transport using a forklift

When transported by a forklift, the unit must remain mounted on the pallet. The lifting rate should be kept to a minimum. Due to its top-heaviness, the unit must be secured against tipping over. To prevent any damage, the unit must be placed on a level surface.

- Manual transport


For the manual transport, a wooden/plastic pallet can be used. Using ropes or carrying straps, a second or third handling configuration is possible. With this type of handling, it is advised that the maximum permissible inclination angle of 45 degree is not exceeded. If transport in an inclined position cannot be avoided, the unit should be taken into operation one hour after it has been moved into final position.



⚠ ATTENTION: DUE TO THE HIGH CENTER OF GRAVITY, LOW OVERTURNING MOMENT, THE UNIT MUST BE SECURED AGAINST TIPPING OVER

Required service space


Below you will find the minimum space required to be able to complete service and maintenance tasks on the units.



Note:

- If air inlet and/or outlet ducts are connected, portion airflow and capacity in heat pump unit will lose.
- If the unit connects with air ducts it should be DN 160mm for pipes or 160mm internal diameter flexible hose. Total length of the ducts should not be longer than 8m or the maximum external static pressure should not exceed than 60Pa. Be in mind of bending site of the duct no more than 4m.

Installation overview




ATTENTION:

- The one-way safety valve must be installed. If not, it could cause damage to the unit, or even hurt people. The set point of this safety valve is 0.7MPa. For the installation place please refer to the pipeline connection sketch.
- The discharge pipe connected to the one-way safety valve is to be installed in a continuously downward direction and in a frost-free environment.
- The water may drip from the discharge pipe of the one-way safety valve and that this pipe must be left open to the atmosphere.
- The one-way safety valve is to be operated regularly to remove lime deposits and to verify that it is not blocked. Please be ware of burn, because of the high temperature of water.
- The tank water can be drained through the drainage hole on the bottom of the tank.

- After all the pipes installed, open stop valves of the cold-water inlet and hot water outlet to fill the tank.
- When there is water flowing out from water outlet pipe which means the tank is full. If any leakage, please repair.
- If the inlet water pressure is less than 0.15MPa, a pressure pump should be installed at the water inlet. If water pressure from supply is greater than 0.65 MPa, the pressure-reducing valve is necessary to be installed at the water inlet pipe.
- Otherwise, please make sure the drainage vent is at the lowest place. Recommending the inclination angle of unit to be ground should no more than 2degree

Installation Positions

- 1) Waste heat can be useful heat Units can be installed near the kitchen, in the boiler-room or the garage, basically in every room which has a large number of waste-heat, so that the unit will have a higher energy efficiency even with very low outside temperatures during the winter



- 2) Hot water and dehumidifier
Units can be placed in the laundry room or clothing room. When it produces hot water, it will lower the temperature and dehumidifies the room as well. The advantages can be experienced particularly in the high humid season.



NOTE:

Choose the right path to move the unit.

This unit complies with the relevant technical standards of electrical equipment.

Water loop connection

Please pay attention to the below points when connecting the water loop pipe:

- Try to reduce the water loop resistance
- Make sure there is nothing in the pipe and the water loop is smooth, check the pipe
- carefully to see if there is any leak, and then pack the pipe with the insulation.
- Install the one-way valve and safety valve in the water circulation system.
- The nominal pipe wide of the field- installed sanitary installations must be selected on the basis of the available water pressure and the expected pressure drop within the piping system.
- The water pipes may be of the flexible type. To prevent corrosion damage, make sure that the materials used in the piping system are compatible.
- When installing the pipe-work on the installation site, any contamination of the piping system must be avoided.

Water filling and water emptying

Water filling:

If the unit is used for the first time or used again after emptying the tank, please make sure that the tank is full of water before turning on the power.

- 1) Open the cold water inlet and hot water outlet.
- 2) Start the water filling. When there is water normally flowing out from the hot water outlet, the tank is full.
- 3) Turn off the hot water outlet valve and water filling is finished.

⚠ ATTENTION: Operation without water in water tank may result in damage of auxiliary e-heater.

Water emptying:

If the unit needs cleaning, moving etc., the tank should be emptied.

- 1) Close the cold water inlet valve.
- 2) Open the hot water outlet valve and open the manual valve of drain pipe.
- 3) Start the water emptying.
- 4) After emptying, close the manual valve.

Wire connection

- The specification of the power supply wire is 3*2.5mm²
- There must be a switch when connecting the unit to the power system. The current of the switch is 16A.
- The unit must be installed with a creepage breaker near the power supply and must be effectively earthed. The specification of the creepage breaker is 30mA, less than 0.1sec.

The appliance must be installed in accordance with national gas wiring regulations.


Trial running

Checks before trial running

- Check both the water in the tank as well as the water pipe connection.
- Check the power system, make sure that the power supply is normal and the wire connection is correct.
- Check the inlet water pressure, make sure that the pressure is sufficient (above 0.15Mpa).
- Check if any water flows out from the hot water outlet, make sure that the tank is full of water before turning on the power.
- Check the unit, make sure everything is correct before turning 'ON' the power of the unit, check the light on the wire controller when the unit runs.
- Use the wire controller to start the unit.
- Listen to the unit carefully when turning 'ON' the power of the unit. Turn the power 'OFF' when you hear an abnormal sound.
- Set a reasonable temperature of the water, a higher setting will result in higher energy consumption.

OPERATION THE UNIT

User interface and operation



1) Power 'ON'

When turning 'ON' the power, whole icons are displayed on the controller screen for 3 seconds. After checking that everything is correct, the unit enters into the standby mode.



2) button

Press this button and keep for 2 seconds when the unit is standby, the unit can be turned 'ON'. Press this button and keep for 2 seconds when the unit is running, the unit can be turned 'OFF'. Short press this button to entry or exit the parameter setting or checking.



3) and buttons

1' These are the multi-purpose buttons. They are used for the temp setting, parameter setting, parameter checking, clock adjustment and adjustment of the timer.

2' During running status, press  or  button to adjust the setting temperature directly.

3' Press these buttons when the unit is on clock setting status, the hour(s) and the minute(s) of the clock time can be adjusted.

4* Press these buttons when the unit is on timer setting status, the hour(s) and the minute(s) of the timer 'ON'/'OFF' can be adjusted.

5* Press  and  buttons at the same time and hold for 5 seconds, the buttons are locked.

6* Press  and  buttons at the same time and hold for 5 seconds again, the buttons are unlocked.

4) button

Clock setting:

1* After power on, short press button to  entry the clock setting interface, hour and minute icons "88:88" flash together;

2* Short press  button to switch hour/minute setting, press the  and  buttons to set the exact hour(s) and minute(s);

3* Press  button again to confirm and exit.

Timer setting:

4* After power on, short press  button for 5 seconds to enter the timer setting interface, the timer with icon  and hour icon "88:" flash together;

5* Press the  e  buttons to set the exact hour(s).

6* Press  button to transfer to minute setting, minute icon ":88" flash, press the o(s)  and  buttons to set the exact minute(s).

7* Press  button again to transfer to timer off setting, the timer off icon  and hour icon "88:" flash together.

8* Press the and  e  buttons to set the exact hour(s)

9* Press  button to transfer to minute setting, minute icon ":88" flash, press the and buttons to set the exact minute(s).

10* Press  button again to save and exit the timer setting interface.

Press  button to cancel the timer settings during the timer 'ON' (or timer 'OFF') programming.

NOTE:

1* The timer 'ON' and timer 'OFF' functions can be set at the same time.

2* The timer settings are repeating.

3* The timer settings are still valid after a sudden power cut.

5) button

When the heat pump is ON, press this button to turn 'ON' the electrical heater. The heater icon  will be showed, and the electrical heater will work according to the control program.

When the heat pump is ON, press this button and hold for 5 seconds to enable or disable the fan ventilation function.

When the heat pump is OFF, press this button to enter E-heater mode.

6) buttons

- 1) Check the temperatures and EXV open steps.
 - Press this button to enter temp and EXV open step checking
 - Press the and buttons  e  to check the temp sensor values and EXV open steps (parameters A-L).
- 2) Check the system parameters
 - In any status, press this button and hold for 5 seconds, enter the system parameter checking interface.
 - Press the and buttons  e  to check the system parameters.
- 3) Adjust the system parameters
 - When the unit is off, press  for 5 seconds, enter the parameter checking interface.
 - Press  ou  or button to select the parameter, and press button to choose this parameter.
 - Press  and  and buttons to adjust the selecting parameter, then press  to confirm the setting

If no action to the buttons for 10 seconds, the controller will exit and save the setting automatically.

NOTE: Once the parameters have been set, the users cannot change the parameters by themselves. Please ask a qualified service person to do this when required.

7) Error codes

During standby or running status, if there is a malfunction, the unit will stop automatically and show the error code on the right part screen of the controller.



LED icons

1) Hot water available

The icon indicates that the domestic hot water temperature reaches the set point. The hot water is available for use. Heat pump is standby.

2) Fan ventilation

The icon indicates that the fan ventilation function is enabled.

When the unit is on, press the  button and hold it for 5 seconds the fan ventilation function can be enabled or disabled. If this function is enabled the fan will continue working to ventilate the air, when the water temperature reaches the set point and unit is standby. If this function is disabled the fan will stop, when the water temperature reaches the set point and unit is standby.

- 3) **Electrical heating** 

The icon indicates that the electrical heating function is enabled. The electrical heater will work according to the control program.
- 4) **Defrosting** 

This icon shows the heat pump is under defrosting.
- 5) **Heating** 

This icon shows the heat pump is working.
- 6) **Key lock** 

This icon indicates the key lock function is enabled. The keys cannot be operated until this function is disabled.
- 7) **Water temperature display on left part of the** 

The display shows the setting water temperature.
When checking or adjusting the parameters, this section will display the relating parameter number.
- 8) **Water temperature display on right part of the** 

The display shows the current downside temperature of the water tank.
When checking or adjusting the parameters, this section will display the related parameter value.
In case any malfunction occurs, this section will display the related error code.
- 9) **Time display** 

The display shows the clock or timer.
- 10) **Timer 'ON'** 

The icon indicates that the "ON" timer function is activated.
- 11) **Temporizador 'OFF'** 

The icon indicates that the "OFF" timer function is activated.
- 12) **Erro** 

The icon indicates there is malfunction.
- 13) **WIFI** 

The icon indicates that WiFi is connected.

Extra PV control function:

Add PV switch in the main control board.

When the parameter 17 is set as 0: It is in manual setting status, users can directly operate  and  the and button of the wire controller to change the set temperature;

When the parameter 17 set as 1: it is auto setting status, the target temperature will be set automatically according to the parameters of 18/19 and the status of PV Switch. Direct manipulation with + / - keys do not change the set temperature, but will response to the operation action by sound;

When the PV Switch is closed, the target temperature will be directly changed to the set value of parameter 18. When the PV Switch is disconnected, the target temperature will be directly changed to the set value of parameter 19.

WIFI

Install the App

Method 1:

Scan the QR code to download the App, Giapp, for iOS system and Android system.
Finish the download and install it.

Notes: Please scan the QR code by browser for Android system.




Method 2:

Search the App, Giapp, in App store for iOS system or in Google Play Store for Android system. Finish the download and install it.



Register

Open the App:



After click "Allow", enter next interface.



Click "Agree". Choose country and type mobile number or email address to get the message of verification code. Please set the password, and remember it.

Privacy Policy

We pay high attention to the privacy of personal information. To fully present how we collect and use your personal information, we revised the Privacy Policy in detail in compliance with the latest laws and regulations. By clicking I Agree, you agree that you have fully read, understood, and accepted all the content of the revised Privacy Policy. Please take your time to read the Privacy Policy. If you have any questions, please contact us anytime.

[Privacy Policy](#)

Disagree Agree

Register

Bulgaria +359

Mobile Number/Email

Get Verification Code

Enter Verification Code

Verification code has been sent to your mobile phone ***** Resend (55s)

Set Password

Password contains 6 to 20 characters, including letters and digits

Done

App configuration

After setting the password to log in the app, add the device. Click "Large Home Applications" and "Water Heater" to next interface.

No devices, please add

Add Device

Home Smart Me

Cancel Other Mode


Reset the device first.

Power on the device and confirm that indicator light rapidly blinks

Resetting Devices >

Confirm indicator rapidly blink

Please connect the Wi-Fi module with heat pump unit. At the same time, please keep the module and mobile devices can receive the same networks.




Method 1:

Power on the heat pump unit, and keep pressing the button and the button at the same time for 5 seconds. The icon will be flashed. When the Wi-Fi indicator keeps fast-flashing, please click the "Confirm indicator rapidly blink".

Method 2:

Power on the heat pump unit, and keep pressing the + and button at the same time for 5 seconds. The icon will be flashed. When the Wi-Fi indicator keeps fast-flashing, please click the "Confirm indicator rapidly blink".




Notes: when the icon of set flashes quickly, it mean the controller is in the Wi-Fi mode. When it flashes slowly, it means the controller is connecting with the App. During the connection, if the icon of set is extinguished, it means the App connection with the unit is finished.

If the mobile is not connected with Wi-Fi from the router, the interface will be automatically skipped to the following interface.




Click "go to connect" to set the mobile's Wi-Fi.

If the mobile is already connected with the Wi-Fi from the router, please type the password and click "Confirm" in the next interface.




After click "Confirm", the Wi-Fi module, mobile device and Wi-Fi router begin to be connected. Finish the connecting, and the interface will be skipped to the next interface.




In this interface, the device (heat pump unit) can be named as you want. Click "Done" to finish the App installation. The screen of the mobile device will display the app control interface.

App operation



1.  **Modify button**
Click it to enter the modify interface.



2. Temperature setting bar

Move the ball to left or right by finger to set the setting temperature.

3. Setting temperature value


This value will be changed according to the location of the ball in the temperature setting bar.

4. Water temperature value in the tank.


This value is detected by the water temperature sensor in the water tank.

5. Mode button

Click the mode button to enter the mode interface. In the mode interface, two modes including heating mode and heating fan mode can be selected.

6. Timer button


Press this button to enter timer interface.




Click "Add" to set the schedule.

The screenshot shows the 'Add Schedule' screen. At the top left is a back arrow. The title 'Add Schedule' is centered at the top, and the 'Save' button is at the top right. Below the title is a scrollable list of times. The visible times are 10:50, 11:51, 12:52, 1:53 AM, 2:54 PM, 3:55, and 4:56. Below the time list is a section for repeating the schedule, with 'Repeat' and 'Sun. Mon.' followed by a right arrow. Below that is a 'Note' field with a right arrow. Below the note is a 'Notification' toggle switch, which is currently off. At the bottom is an 'ON/OFF' toggle switch, which is currently on, followed by a right arrow.

Please in this interface, setting the time and day for timer on and timer off. After setting, please click "Save" to confirm and save. The timer setting will be displayed in next interface. In this interface, click "Add Schedule" to add another timer on/off.



Slide the schedule from left to right to delete the schedule.



7. On/Off button

Click this button to switch on or switch off the heat pump unit.

PARAMETER CHECKING AND ADJUSTMENT

Parameter list

Some parameters can be checked and adjusted by the controller. Below is the parameter list.

Parameter No.	Description	Range	Default	Remarks
0	Tank water setting temp.	10 ~75°C	50°C	Adjustable
1	Water temperature gap to restart	2 ~ 15°C	5°C	Adjustable
2	<i>E-heater setting temp.</i>	10 ~85°C	55°C	Adjustable
3	<i>E-heater delay time</i>	0~90min	6	t * 5 min
4	Week disinfection temperature	50 ~75°C	70°C	Adjustable
5	High temp disinfection time	0 ~ 90min	30 min	Adjustable
6	Defrosting period	30~90min	45 min	Adjustable
7	Defrosting entry coil temp.	-30~0°C	-7°C	Adjustable
8	Defrosting exit coil temp.	2 ~ 30°C	6°C	Adjustable
9	Max defrosting cycle period	1 ~ 12min	8 min	Adjustable
10	Electronic expansion valve adjustment	0/1	1	Adjustable (0-manual~ 1-auto)
11	Target over-heat degree	-9 ~ 9°C	5°C	Adjustable
12	Steps of manually adjusting the electronic expansion valve	10 ~ 50step	35 step	Adjustable
13	Disinfection start up time adjusting	0~23	23	Adjustable (hour)
14	Parameter of solar water pump	0/2	0	Adjustable (0 without water pump~ 1 with water pump~ 2 Return water pump)
15	Solar water pump start return difference	2-20°C	10	Adjustable
16	High temp disinfection interval	1-28 dia	7	Adjustable
17	Temperature setting mode	0/1	0	Adjustable (0-manual~ 1-auto)
18	Set temp with PV	10-75℃	60	Adjustable
19	Set temp without PV	10-75℃	50	Adjustable
20	Return water pump stop time	1-99*10	3	Adjustable by N*10 min
21	Return water pump running time	1-30min	3	Adjustable
22	Whether the defrost auxiliary heating need to be turned on	0/1	0	0 - Off, 1 - On

23	Fan type	0/1	0	0 - AC, 1 - DC
24	DC fan speed setting	50-140	88	Adjustable N*10RPM
25	Host communication address setting	1-16	1	Using communication port CN5
A	Lower part tank water temp.	-9 ~ 99°C	Actual testing value. Error code P1 will be shown in case of a malfunction	
B	Upper part tank water temp.	-9 ~ 99°C	Actual testing value. Error code P2 will be shown in case of a malfunction	
C	Evaporator coil temp.	-9 ~ 99°C	Actual testing value. Error code P3 will be shown in case of a malfunction	
D	Return gas temp.	-9 ~ 99°C	Actual testing value. Error code P4 will be shown in case of a malfunction	
E	Ambient temp.	-9 ~ 99°C	Actual testing value. Error code P5 will be shown in case of a malfunction	
F	Electronic expansion valve step	10 ~ 47 step	N*10 step	
H	Temp of solar thermal collector	0-140°C	Measured value` if failure` show P6	
L	DC fan speed	0-140	N*10` if failure` shows P9	

Malfunctioning of the unit and error codes

When an error occurs or the protection mode is triggered, the circuit board and the wired controller will both display the error message.

Protection/ Malfunction	Error code	Possible reasons	Corrective actions
Standby			
Normal running			
Lower part tank water temp. sensor failure	P1	1) The sensor open circuit 2) The sensor short circuit 3) PCB board failure	1) Check the sensor connection 2) Replace the sensor 3) Change the PCB board
Upper part tank water temp. sensor failure	P2	1) The sensor open circuit 2) The sensor short circuit 3) PCB board failure	1) Check the sensor connection 2) Replace the sensor 3) Change the PCB board
Evaporator coil temp. sensor failure	P3	1) The sensor open circuit 2) The sensor short circuit 3) PCB board failure	1) Check the sensor connection 2) Replace the sensor 3) Change the PCB board
Return air temp sensor failure	P4	1) The sensor open circuit 2) The sensor short circuit 3) PCB board failure	1) Check the sensor connection 2) Replace the sensor 3) Change the PCB board
Ambient temp. sensor failure	P5	1) The sensor open circuit 2) The sensor short circuit 3) PCB board failure	1) Check the sensor connection 2) Replace the sensor 3) Change the PCB board
Solar collector temp. sensor failure	P6	1) The sensor open circuit 2) The sensor short circuit 3) PCB board failure	1) Check the sensor connection 2) Replace the sensor 3) Change the PCB board

DC fan failure	P9	1) Connecting wire off 2) DC fan failure 3) PCB board failure	1) Check the DC fan connection 2) Replace the DC fan; 3) Change the PCB board
Emergency switch off	EC	1) Connecting wire off 2) PCB board failure	1) Check the bridge wire 2) Change the PCB board
High pressure protection (HP Switch)	E1	1) Too high air inlet temperature 2) Less water in the tank 3) The electronic expansion valve assembly blocked 4) Too much refrigerant 5) The switch damaged 6) there is air in the refrigerant system. 7) PCB board failure	1) Check if the air inlet temp is over the working limited 2) Check if the tank is full of water. If not, charge water 3) Replace the electronic expansion valve assembly 4) Discharge some refrigerant 5) Replace a new switch 6) Discharge and then recharge the refrigerante 7) Change the PCB board
Low pressure protection (LP Switch)	E2	1) Too low air inlet temperature 2) The electronic expansion valve assembly blocked 3) Too less refrigerant 4) The switch damaged 5) The fan assembly can not work 6) PCB board failure	1) Check if the air inlet temp is over the working limited 2) Replace the electronic expansion valve assembly 3) Charge some refrigerant 4) Replace a new switch 5) Check if the fan working when the compressor working. If not, some problems with the fan assembly 6) Change the PCB board
Over heat protection (HTP Switch)	E3	1) Too high tank water temp 2) The switch damaged 3) PCB board failure	1) If the tank water temp is over 85C, the switch will open and the unit will stop for protection. After the water comes to normal temp, system will recover 2) Replace a new switch 3) Change the PCB board
Defrost	Defrosting indicate		
Communication failure	E8	1) The communication circuit is loosen 2) PCB board failure 3) Wired controller failure	4) Check the communication circuit connection 5) Change the PCB board 6) Change the line controller

MAINTENANCE

Maintenance activities

In order to ensure an optimum operation of the unit, a number of checks and inspections on the unit and the field wiring have to be carried out at regular intervals, preferably yearly.

- Clean the water filter to keep a good water quality. Lack of water and dirty water can damage the unit.
- Keep the unit in a place where it is dry and clean, and which has good ventilation. Clean the heat exchanger every one to two months.
- Check each part of the unit and the pressure of the system. Replace the defect part if there is any, and recharge the refrigerant if it is required.
- Check the power supply and the electrical system, make sure the electrical components are good, and the wiring is well. If there is a damaged part or a strange smell, please replace it in time.
- If the heat pump is not used for a long time, please drain out all the water from the unit and seal the unit to keep it good. Please drain the water from the lowest point of the unit to avoid freezing in winter. Water recharge and full inspection on the heat pump is required before it is restarted.
- Do not turn the power 'OFF' when you use the unit continuously, or the water in the pipe will freeze and crack the pipe.
- Keep the unit clean by means of soft damp cloth, no maintenance is required by the operator. It is recommended to clean the tank and e-heater regularly to keep an efficient performance. It is recommended to set a lower temperature to decrease the heat release, and save energy.

It is recommended to set a lower temperature to reduce heat release and save energy.
Clean the air filter regularly to keep an efficient performance.

TROUBLESHOOTING

This part provides useful information for diagnosing and correcting certain troubles which may occur. Before starting the troubleshooting procedure, carry out a thorough visual inspection of the unit and look for obvious defects such as loose connections or defective wiring. Before contacting your local dealer, read this chapter carefully, it will save you time and money.

 **WHEN CARRYING OUT AN INSPECTION ON THE SWITCH BOX OF THE UNIT, ALWAYS MAKE SURE THAT THE MAIN SWITCH OF THE UNIT IS SWITCHED 'OFF'**

The guidelines below might help to solve your problem. If you cannot solve the problem, consult your installer/local dealer.

No image on the controller (blank display). Check if the main power is still connected.

One of the error codes appears, consult your local dealer.

The scheduled timer does work but the programmed actions are executed at the wrong time (e.g. 1 hour too late or too early). Check if the clock and the day of the week are set correctly, adjust it if necessary.

ENVIRONMENTAL INFORMATION

This equipment should only be serviced or dismantled by professional trained personnel.

This equipment contains R290 refrigerant in the amount as stated in the specification. Do not vent R290 into the atmosphere: R290 is with a Global Warming Potential (GWP) = 3°

DISPOSAL REQUIRIMENTS

Dismantling of the unit, treatment of the refrigerant, oil and other parts must be done in accordance with relevant local and national legislation.




Your product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, oil and other parts must be done by a qualified installer in according to relevant local and national legislation. Units must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring that this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

WIRING DIAGRAM

Please refer to the wiring diagram on the electric box.



TECHNICAL SPECIFICATION

TECHNICAL DATA		80L	120L
Power supply	V/Ph/Hz	220~240V/1/50Hz	
Water tank Volume	L	80	120
Rated Power	W	416 + 1600 (resist. elétrica)	
Rated Current	A	1.81 + 6.8 (resist. elétrica)	
Max. Outlet water temperature range (without using E-heater)	°C	65	
Max. water temperature	°C	75	
Min. Water temperature	°C	10	
Ambient working temp.	°C	-7~43	
Max. discharge pressure	bar	30	
Max. suction pressure	bar	10	
Refrigerant type		R290	
Compressor	Type	Rotary	
	Bran	GMCC	
	Model	RDSN82V11TZE	
Fan motor	Type	Asynchronous motor	
	W	15	
	RPM	880	
Air flow	m3/h	240	
Duct diameter	mm	DN160 (Fit flexible 180/200mm)	
Max allowed pressure of tank	bar	10	
Inside body material of tank		Inox 2205	
Auxiliary electrical heater	kW	1.6	
Electronic expansion valve		yes	
Magnesium stick		Magnesium stick	
Solar heat exchanger		Opcional	
Hot water outlet	inch	G 3 / 4	
Solar heat exchanger inlet/outlet	inch	G 3 / 4	
Entrada de água fria	inch	G 3 / 4	
Drainage	inch	G 3 / 4	
Condensed water outlet	inch	G 1 / 2	
Heat pump heat exchanger material		Micro channel heat exchanger(Aluminium alloy)	

Net Dimensions	φ510x1078	Φ510x1328
Packing Dimensions	570x570x1185	570x570x1435
Net Weight	46	51
Gross Weight	61	67

TEMPERATURE SENSOR R-T CONVERSION TABLE

$R_{25}=5.0K\Omega \pm 1.0\%$ $R_{25-50} = 3470K\Omega \pm 1.0\%$

°C	Rmin/KΩ	KΩ	Rmax/KΩ	°C	Rmin /KΩ	KΩ	Rmax/ KΩ	°C	Rmin/KΩ	KΩ	Rmax/ KΩ
-20	36.195	37.303	38.441	21	5.779	5.84	5.91	62	1.343	1.374	1.406
-19	34.402	35.437	36.499	22	5.558	5.62	5.68	63	1.301	1.331	1.362
-18	32.709	33.676	34.668	23	5.346	5.40	5.46	64	1.26	1.29	1.321
-17	31.109	32.012	32.939	24	5.144	5.19	5.25	65	1.221	1.25	1.28
-16	29.597	30.441	31.306	25	4.95	5	5.05	66	1.183	1.212	1.242
-15	28.168	28.957	29.765	26	4.761	4.81	4.86	67	1.147	1.175	1.204
-14	26.816	27.554	28.308	27	4.58	4.63	4.68	68	1.111	1.139	1.168
-13	25.538	26.227	26.932	28	4.408	4.45	4.50	69	1.077	1.105	1.133
-12	24.328	24.972	25.631	29	4.242	4.29	4.34	70	1.045	1.072	1.099
-11	23.183	23.785	24.4	30	4.084	4.13	4.18	71	1.013	1.04	1.067
-10	22.098	22.661	23.236	31	3.933	3.98	4.03	72	0.983	1.009	1.035
-9	21.071	21.598	22.135	32	3.788	3.83	3.88	73	0.953	0.979	1.005
-8	20.098	20.59	21.093	33	3.649	3.69	3.74	74	0.925	0.95	0.975
-7	19.176	19.636	20.106	34	3.516	3.56	3.61	75	0.897	0.922	0.947
-6	18.301	18.732	19.171	35	3.388	3.43	3.48	76	0.871	0.895	0.919
-5	17.472	17.875	18.285	36	3.266	3.31	3.36	77	0.845	0.869	0.893
-4	16.686	17.063	17.446	37	3.149	3.19	3.24	78	0.82	0.843	0.867
-3	15.94	16.292	16.65	38	3.037	3.08	3.12	79	0.796	0.819	0.842
-2	15.231	15.561	15.896	39	2.929	2.97	3.01	80	0.773	0.795	0.818
-1	14.559	14.867	15.18	40	2.826	2.87	2.91	81	0.751	0.773	0.795
0	13.92	14.208	14.501	41	2.726	2.77	2.81	82	0.729	0.751	0.773
1	13.313	13.582	13.856	42	2.631	2.67	2.71	83	0.708	0.729	0.751
2	12.736	12.988	13.244	43	2.54	2.58	2.62	84	0.688	0.709	0.73
3	12.188	12.423	12.662	44	2.452	2.49	2.53	85	0.668	0.689	0.709
4	11.666	11.887	12.11	45	2.368	2.40	2.45	86	0.649	0.669	0.69
5	11.17	11.376	11.585	46	2.287	2.32	2.36	87	0.631	0.651	0.671
6	10.698	10.891	11.086	47	2.209	2.25	2.29	88	0.613	0.632	0.652
7	10.249	10.429	10.611	48	2.135	2.17	2.21	89	0.596	0.615	0.634
8	9.822	9.99	10.16	49	2.063	2.10	2.14	90	0.579	0.598	0.617
9	9.414	9.572	9.73	50	1.994	2.03	2.07	91	0.563	0.581	0.6
10	9.027	9.173	9.321	51	1.927	1.96	2.00	92	0.548	0.566	0.584
11	8.657	8.794	8.932	52	1.863	1.90	1.93	93	0.533	0.55	0.568
12	8.305	8.432	8.561	53	1.802	1.83	1.87	94	0.518	0.535	0.553
13	7.969	8.088	8.208	54	1.743	1.77	1.81	95	0.504	0.521	0.538
14	7.648	7.76	7.872	55	1.686	1.72	1.75	96	0.49	0.507	0.524
15	7.343	7.446	7.551	56	1.631	1.66	1.70	97	0.477	0.493	0.51
16	7.051	7.148	7.245	57	1.579	1.61	1.64	98	0.464	0.48	0.496
17	6.773	6.863	6.953	58	1.528	1.56	1.59	99	0.452	0.467	0.483
18	6.507	6.5911	6.675	59	1.479	1.51	1.54	100	0.439	0.455	0.47
19	6.253	6.331	6.41	60	1.432	1.46	1.49				
20	6.011	6.083	6.156	61	1.386	1.41	1.45				



NIPON TECHFORCOMFORT
www.niponcomfort.com